



**CRISC-070B PRODUCT MANUAL**

**CRUX WIRELESS CHARGING POWER BANK**

**MODEL NO CRISC-070B**

**PRODUCT AND WARRANTY INFORMATION**

**THANK YOU FOR CHOOSING OUR PRODUCTS. PLEASE READ THE FOLLOWING INFORMATION CAREFULLY BEFORE USE.**

**NOTICE**

1. Do not place metal or other objects between the product and the phone when wireless charging.
2. Do not squeeze or crush the product.
3. Do not use this product in a hot, humid, or corrosive environment to avoid damage to the circuit.
4. Do not replace any elements of the product or make any changes.
5. Only qualified service personnel may install or repair this product.
6. Please use approved adapters, do not connect incompatible adapters.
7. Do not apply large amounts of force on the product. If the product has any damage, such as depression, puncture, stains, deformation, corrosion, etc., prohibit use of the product, and contact us.

**PRODUCT PACKING LIST**

ITEM	QUANTITY
CRISC-070B (Power Bank)	1
CRISC-070C (Power Adapter)	1
Cable	1
Instructions	1


**PARAMETERS**

**PRODUCT NAME:** CRISC-070B  
**BRAND:** CRUX INTERFACING SOLUTIONS  
**MODEL NO.:** CRISC-070B  
**Color:** Black  
**WEIGHT:** ~ 73.5g  
**SIZE:** 69.7mm x 90.6mm x 8.4mm  
**BATTERY CAPACITY:** 3.7 - 2000mAh  
**INPUT VOLTAGE / CURRENT:** 5V - 5W  
**OUTPUT VOLTAGE / CURRENT:** 5V - 5W  
**OPERATING TEMPERATURE:** 0 - 45°C  
**DISCHARGE STANDARD:** 1.5C

Pure lithium cobalt oxide batteries, 12um ceramic diaphragm.



**INSTRUCTIONS**

The bank should be viewed as two sides: Side A is the nano suction side with product information on its surface. Use this side to snap onto your phone or Qi-enabled device. Then press the power button on the bank to charge your device. Side B is the side with the CRUX logo on it. You can use this side to charge the power bank, via the CRISC-070A charging pad.



**USE THE BANK TO CHARGE YOUR PHONE**

Face Side A toward the phone to charge. Press the button on the side to activate the bank. Indicator lights remain on when charging. To avoid energy loss, double-tap the button to turn off the bank when not in use.



There are 4 power indicator lights located on the power bank. Each represent the battery level.

Press the power button to turn on the indicator lights. If there are no devices near the bank, the bank will automatically shut down.

You can also place the power bank on the CRISC-070A charging base to turn on the indicator lights.

**CERTIFICATION**

Crux Interfacing Solutions is a registered trademark and all rights reserved. Patents: The product passed the laboratory test and has the necessary certificate of conformity.

**SERVICE**

1. During the warranty period, non-human damage can be repaired.
2. Please provide proof of purchase or warranty card to enjoy warranty service.
3. This product warranty is limited to the maintenance or replacement of this product at its sole discretion. Batteries and other consumables with limited service life cannot be warranted.
4. This limited warranty is valid only if the product is used for its original purpose. It does not apply to damage or loss cause by negligence; physical abuse; misuse; or accident.

**WARRANTY CARD**

Customer Name	
Mobile Phone	
Contact Address	
Model No.	
Date of Purchase	
Dealer Shop	
Failure Description	

For more efficiency on handling your case, please provide correct info and mail with the failure product to CRUX Interfacing Solutions. This limited warranty for the product shall last for 12 months from the date of original purchase.

**Customer Service**  
 (818) 609-9299  
 www.cruxinterfacing.com